

## You have the SLO. How do you use it?

This camera's controls are simplified versions of the controls on a standard SLR.

### Load film into the camera.

Push the slider to unlock the door, then press the button on the the front corner to open the door.


Pull the *rewind* ④ knob up until it sticks, put the film roll into the camera, then press the knob back down.


Pull the film across the backplate and through the slot in the takeup spool. Crease the film to stop it from sliding out.

Turn the winding ② knob several times until the film wraps around the takeup spool.

Put the door back on hinge-side first, and make sure it's locked.


## Ready the film.

Make sure the shutter is fully closed. One shutter  button should be completely in the up position, and the other completely down. Push the shutter buttons a few times to make sure they're moving smoothly.

Advance the film to the first frame by turning the winding knob. The indicator  should turn a full 360 degrees.

## Take your photos.

Make sure the shutter is fully closed. One shutter button should be completely in the up position, and the other completely down.

Adjust the aperture by turning the aperture  wheel.

Take a photo by pressing the raised shutter button. The other button will toggle up.

Advance to the next frame by turning the winding knob until the indicator moves 90 degrees.


## Rewind the film.

Pull the winding knob up to allow the film to be rewound.

Turn the rewind knob until the film is completely inside the canister (there will be no more resistance)

Pull the rewind knob all the way up and remove the film roll.

## Switch lenses.

Remove the lens by holding the aperture wheel and turning the  lens clockwise.